Guide of Install cccam plugs in openatv image

1.download softcam-feed-mipsel_1.0_all.ipk file from internet

2.Copy file to your USB disk root catalog

3.Insert USB disk to your box

4.Select file and install like below

Press RCU manu---setup---software management---install local extension---media/hdd---install extensions---softcam-feed-mipsel_1.0_all.ipk---green key










5.Select plugs to install cccam2.3.0

Press RCU exit key to exit above manu, press RCU manu---plugins---ok---green key








Select softcams press ok key to insall cccam 230 plugin






6.check your cccam state

Press RCU green key you can check and active your cccam







Press right arrow key change to cccam2.3.0 press green key active cccam function





Now you can use your cccam

7. Cccam info



You can press yellow key to check your cccam info

8.If you can’t see the language in english you can restart your box

